



User Manual
Safelock24 display

Contents

- Public normal mode..... 3
 - Using pass 3
 - Putting the safe into use 3
 - Terminate use of safe deposit box 4
 - Using PIN..... 5
 - Putting the safe into use 5
 - Terminate use of safe deposit box 6
- Public PIN mode..... 8
 - Putting the safe into use 8
 - Terminate use of safe deposit box 9
- Decided only pass mode 11
 - Putting locker into use 11
 - Terminate use of safe deposit box 11
- Private password mode..... 12
 - Putting safe in use 12
 - Terminate use of locker..... 12




Public normal mode


Use pass

Putting the safe into use

Press the "Storage" button under the CARD section



Holds your pass in front of the reader




A free safe will open. You can plug in your device and close the safe again.




Terminate use of safe deposit box

Press the "Take out" button under the CARD section



Holds your pass in front of the reader




The safe you were using will open. You can disconnect your device and close the safe again.




Using PIN

Putting the safe into use

Press the "Storage" button under the Password section




Enter a 4-digit pin code




After this, enter the PIN code again for confirmation. And press "ENTER." A free safe will open. You can plug in your device and close the safe again. It is important to remember the locker number.

Terminate use of safe deposit box


Press the "Take out" button under the Password section



Select the locker you have in use



Enter the PIN code you set at commissioning and press "ENTER"



The safe you are using will open. You can disconnect your device and close the safe again.

Public PIN mode


How to change and set the mode of the locker can be read in the management manual.

Putting the safe into use

Press the "Storage" button under the Password section



Enter a 4-digit pin code




After this, enter the PIN code again for confirmation. And press "ENTER." A free safe will open. You can plug in your device and close the safe again. It is important to remember the locker number.

Terminate use of safe deposit box


Press the "Take out" button under the Password section



Select the locker you have in use



Enter the PIN code you set at commissioning and press "ENTER"




The safe you are using will open. You can disconnect your device and close the safe again.

Closed pass mode

How to change and set the mode of the locker can be read in the management manual.

Putting the safe into use


Holds your pass in front of the reader



The locker assigned to you will open. You can plug in your device and close the safe again.

Terminate use of safe deposit box

Holds your pass in front of the reader



The safe you were using will open. You can disconnect your device and close the safe again.

Locked PIN mode

How to change and set the mode of the locker can be read in the management manual.

Putting the safe into use


Press the "ENTER PASSWORD TO OPEN YOUR LOCKER" button.



The locker assigned to you will open. You can plug in your device and close the safe again.

Terminate use of safe deposit box

Press the "ENTER PASSWORD TO OPEN YOUR LOCKER" button.



The safe you were using will open. You can disconnect your device and close the safe again.